


Programming your new remotes to a receiver



How to program your remotes to the receiver:

- A. Press and release the LEARN1 button at the top of the receiver board (ex 1). Until the learn LED illuminates steady (ex. 2) then release.
- B. Holding the transmitter 3 feet or more from the receiver, press and hold the button on the remote you wish to program to the receiver until the Learn LED flashes and then turns off. (Caution your gate opener may be triggered during this process)
- C. Repeat A and B for all additional remotes.
- D. To learn relay 2, press Learn 2 in Step A and follow the remaining steps.



NOTES ABOUT REMOTES:

You can program up to 400 codes into the receiver. This could mean 1 button on 400 different remotes or this could mean all 4 buttons on 100 remotes or anything in between. Some choose to program all 4 buttons to a single receiver if they are not using multiple gates to eliminate pressing the incorrect button on the remote. To do so follow the programming above with each button of the remote.

Warning you will erase all programmed codes by holding Learn 1 until the Learn LED comes ON and then turns **OFF**.